



Remove spare tire in order to remove shackle bolts



Disconnect upper shock mounting bolts



Install upper shock extensions and new hardware.

Reinstall wheels/tires and torque to spec. Re-check all work performed and torque all hardware to spec. Test drive and have vehicle aligned.