

Install the sway bar offset spacers to the frame using the factory 10mm bolts. Install the sway bar to the offset spacer using the provided 10mm x 1.5 x 20mm bolts and a 14mm socket.



Reinstall the tie-rod using a 21mm socket. Reinstall the sway bar end links using a 13mm socket for the bottom and a 15mm socket for the top.

