



Raise and support vehicle by frame on jack stands



Support rear axle with jack



Disconnect lower shock from mount



Remove u-bolt mounting hardware



Remove u-bolts and axle mounting plate



Carefully lower axle enough to install new block



4WD models shows factory block



4WD models lower axle and remove factory block

## STACK VERSION



Place new block into position (1.0" block shown)



Raise axle and center locating pin on leaf pack. Note: taper



Reinstall axle mounting plate



Tighten hardware and reinstall lower shock into mount

## REPLACE VERSION



Shown (3.0" block) replacing factory block on 4WD models



Place u-bolts over saddle on leaf pack and over axle



Install new hardware

Recheck all work performed, torque hardware and lower vehicle to ground and test drive.