



Raise vehicle securely by frame and support axle with jack..



Work on one side at a time to prevent driveline damage.



Disconnect ABS wiring brackets from axle.



Remove rear lower shock bolt and disconnect shock.



Remove u-bolt nuts and lower plate.



Carefully lower axle and remove u-bolts



Place new lift block into position between axle and leaf pack.



Raise axle and ensure locating pins are properly aligned.



Slide new u-bolts over leaf pack and bumpstop bracket.



Attach lower mounting plate with provided hardware.



Replace shock on mount and ABS line to axle.