

1. The brake line clamps on the axle face down from factory, and will need to be flipped and reinstalled to position the brake line upwards. (1)

2. Bend the original bracket so that the line ends are at the same angle as the lines themselves. (2)

3. Install the small plate between the axle and the brake line bracket using the original bolt at the axle and a provided bolt at the bracket. (3)



4. Release the ABS line from the bracket on the axle so that the line will be loose at full droop. (4)

5. Install the two long brackets with the bends facing up between the axle and the emergency brake cable bracket, use the factory bolts at the axle and the provided bolts at the bracket. (5)

6. Install provided carrier bearing spacers one at a time for ease of install, using provided bolts and washers. Do not tighten completely yet.

7. Arrows should be pointing up and towards the front of the truck. Once both spacers are installed, tighten to factory specs. (6)

