

SKID PLATE SPACER INSTRUCTIONS



Using the hardware provided, install the M8 bolt, washer, skid plate, and 1/2 tall spacer into the back two skid plate mounting points. Use the OEM hardware for the two front mounting parts.

Differential Drop Installation



1. Position a floor jack under the front differential. Raise the pad so that it is touching the diff.



2. Remove the factory 19mm differential mounting nuts and bolts. The OEM washers will be reused.



3. Install the 1" spacers between the differential supports and the front cross-member. Install the new bolts with factory washers and the new nuts and washers.



4. Re-install the skid-plate, use two OEM bolts for the front and the supplied and torque the bolts to factory specs. Re-install the wheels and torque to factory