

REAR COIL SPACER INSTRUCTIONS

Rear Coil Spacer Installation

Position truck on a flat surface, chock the front wheels and lift vehicle by the frame so that the rear wheels are off the ground. Use a floor jack and jack stands or a (2) two post lift if available and remove both rear wheels.

Install one side at a time.

1. Support the rear axle with a jack. Remove the driver side lower shock bolt. You can use a pry bar to slide the shock off the mounting post.
2. Unbolt the sway bar end link at the sway bar.
3. Lower the jack, remove the driver side rear coil. Install coils spacer with nipple going into the recessed area in the bump stop.
4. Reinstall rear coil and spacer, reverse steps 1-3 and repeat on opposite side. Torque all hardware to factory specs.

